


VAC - FORCE 2000 - Spare Parts List

	DESCRIPTION	QTY.	PART #
1	ALLEN KEY	1	VF-067
2	ALLEN KEY HOLDER	1	VF-068
3	AIR SUPPLY CONTROL VALVE	1	VF-062
4	SPRING - AIR INLET	1	VF-061
5	FILTER - AIR INLET	1	VF-057
6	CONNECTION TUBE	1	VF-046
7	O-RING	3	VF-016
8	VENTURI ASSEMBLY	1	VF-082
9	O-RING	1	VF-050
10	BUTTON HEAD SCREW	2	VF-015
11	SAFETY VALVE END CAP	1	VF-004
12	O-RING	2	VF-018
13	SPRING - SAFETY VALVE	1	VF-022
14	SAFETY VALVE	1	VF-003
15	SEAL - SAFETY VALVE	1	VF-077
16	RELEASE BUTTON	1	VF-011
17	SPRING - RELEASE BUTTON	1	VF-023
18	CIRCLIP - RELEASE BUTTON	1	VF-020
19	FILTER - VACUUM	1	VF-058
20	CIRCLIP - VACUUM	1	VF-066
21	SEAL - VACUUM	1	VF-071
22	GRUB SCREW - SAFETY VALVE	2	VF-070
23	VACUUM PAD	1	VF-035
24	GRUB SCREW - LUBRICATOR	1	VF-081
25	ELBOW - MALE SWIVEL	2	VF-065
26	AIR DRILL SUPPLY HOSE	1	VF-063
27	BUTTON HEAD SCREW	6	VF-054
28	HANDLE	1	VF-036
29	RECOIL	3	VF-049
30	SPRING - DRILL FEED LEVER	1	VF-043
31	ROLL PIN	1	VF-052
32	DRILL FEED LEVER	1	VF-045
33	SHOULDER SCREW	1	VF-051
34	FILTER - EXHAUST	1	VF-058
35	SEAL - HANDLE	1	VF-055
36	DRILL FEED ADJUSTMENT	1	VF-041
37	DRILL FEED VALVE	1	VF-012
38	O-RING	2	VF-017
39	TEAR DROP	1	VF-040
40	TUBE BOLT	1	VF-039

	DESCRIPTION	QTY.	PART #
41	LOCATION PIN	1	VF-014
42	HALF NUT	1	VF-026
43	PISTON ROD	1	VF-013
44	SEAL - CYLINDER BASE	2	VF-027
45	CYLINDER BASE ASSEMBLY	1	VF-083
46	BUSH - CYLINDER BASE	1	VF-007
47	PISTON	1	VF-006
48	SEAL - PISTON	1	VF-029
49	PISTON WASHER	1	VF-005
50	HALF NUT	1	VF-025
51	SPRING - AIR CYLINDER	1	VF-053
52	SEAL - CYLINDER CAP	1	VF-028
53	BUSH - CYLINDER CAP	1	VF-008
54	O-RING	1	VF-019
55	CYLINDER CAP	1	VF-010
56	GRUB SCREW	2	VF-021
57	PRESSURE RELIEF VALVE	1	VF-030
58	SPRING - RELIEF VALVE	1	VF-024
59	GRUB SCREW	1	VF-069
60	CAP SCREW	2	VF-064
61A	DRILL CLAMP "A"	1	VF-038
61B	DRILL CLAMP "B"	1	VF-084
61C	DRILL CLAMP "C"	1	VF-085
62	LABEL - CYLINDER BASE	1	VF-086
63	LABEL - SAFETY VALVE	1	VF-087
64	LABEL - CYL. CAP	1	VF-088



We Have The Product With:
ERGONOMICS, SAFETY & PRODUCTIVITY